

Set Lever Pocket Watches

ATTENION: Do Not Pull the Crown Out

To set the hands on certain older pocket watches and all RR approved models, a lever must be shifted first. It is located at 2 o'clock on open-faced models and at 4:30 on hunter case pocket watches. It is grabbed with the thumbnail and pulled out slightly. The crown will then set the hands. Push lever back in all the way when finished stetting and you will be able to wind the watch.



Set Lever Pocket Watches

ATTENION: Do Not Pull the Crown Out

To set the hands on certain older pocket watches and all RR approved models, a lever must be shifted first. It is located at 2 o'clock on open-faced models and at 4:30 on hunter case pocket watches. It is grabbed with the thumbnail and pulled out slightly. The crown will then set the hands. Push lever back in all the way when finished stetting and you will be able to wind the watch.



Set Lever Pocket Watches

ATTENION: Do Not Pull the Crown Out

To set the hands on certain older pocket watches and all RR approved models, a lever must be shifted first. It is located at



2 o'clock on open-faced models and at 4:30 on hunter case pocket watches. It is grabbed with the thumbnail and pulled out slightly. The crown will then set the hands. Push lever back in all the way when finished setting and you will be able to wind the watch.